



● Short Press
 ■ Long Press
 ■ Shift + Press

- 1 _Seq Mode**
 - Seq On/Off ●
 - Seq Menu ■
 - Save current Pattern ■
- 2 _Arp Mode**
 - Arp On/Off ●
 - Arp Menu ■
 - Convert Arp to Seq ■
- 3 _Mutate [Seq or Arp]**
 - Mutate Seq or Arp ●
 - Control Mutate Amount ■
 - Reset Mutations ■
- 4 _Chord & Scale**
 - Chord On/Off ●
 - Chord Menu ■
 - Scale Menu ■
 - Write user Chord ■ Press down + Keys
- 5 _Timing [Seq or Arp]**
 - Show Tempo ●
 - Timing Menu ■
 - Length editing ■
 - Tap Tempo ■ Multiple presses
- 6 _Record**
 - In Stop: Step Rec ●
 - In Play: Real-Time Rec ■
 - Toggle overdub recording ■
- 7 _Stop**
 - Stop Sequence ●
 - Output MIDI Channel ■
 - Panic ●●●
- 8 _Play / Pause**
 - Toggle Play/Pause ●
 - Create Pattern Chain ■
- 9 _Control screen with Encoder**
 - Global Settings ●
 - In Step Rec, navigate steps, select notes for editing ●
 - In pattern chain, navigate/edit pattern chain ●
- 10 _Shift**
 - Hold and press controls to access Shift functions
- 11 _Hold**
 - Arp: Hold Arp notes ●
 - Seq Play: Transpose Hold ■
 - Step Rec: Add silence ■
 - Step Rec + Key: Tie notes ■
 - Real Time Rec: Live erase ■
 - Arp/Seq Off: Sustain notes ■
- 12 _Octave**
 - Press both to reset
- 13 _Pitch Bend & Mod Wheel**
 - Bend and Wheel ●
 - Gate and Spice [Arp or Seq] ■
 - Roll Dice ■

Keyboard Shift functions

- 1 Bank/Octaves**
Seq: Four banks of 16 Patterns
Arp: Arp Octaves
- 2 Seq Pattern/Arp Mode**
Seq: Select Pattern for current Bank
Arp: Select classic Arp Mode [1 - 6]
Arp: Select generative Pattern Mode [7 - 15]
Arp: Use current sequence as Arp Pattern [16]
- 3 Time Div**
Seq or Arp Time Division
- 4 Straight/Triplet/Dotted**
- 5 Sequence Edit**
Nudge steps left or right
Increase/decrease octaves
- 6 Double** Sequence length + duplicate content
- 7 Quantize** Sequence
- 8 Reload** Sequence from saved version
- 9 Clear** Sequence notes
- 10 Undo** Last recording, last Clear, last Reload